

ALL-IN-ONE SECURITY SYSTEM

Quick Start Guide



Troubleshooting

If you are experiencing video loss, verify that all cables are properly and securely connected to the NVR.

- Check your Network Connection
- Check your Username and Password
- Restart the NVR if you have trouble connecting.
 - ✓ Main Menu > Shutdown > Enter Username & Password > Click "Reboot"
 - ✓ To reset your NVR to factory settings, refer to the User manual.



CAUTION!

- The transmission range of the wireless signal may weaken if heavy obstructions, such as concrete, brick, or metal walls are between the NVR and cameras.
- If there are multiple Wi-Fi routers and devices in your environment, it may reduce the wireless bandwidth available. Weak network bandwidth may reduce the video quality or video loss.
- If your video is interrupted and video loss occurs, change Wireless Band Selection from the Auto mode to the Manual mode in the Setup menu, and select a channel with no interference. (See page 16 of the NVR manual).



NVR Setup


KIT Model

SNK-B73047BW

NVR Model

SNR-73207W

• Front



NVR Setup

Package Contents

- ✓ The appearance of the components may differ from the image shown.
- ✓ Accessory category and quantity may differ depending on sales region.
- ✓ The administrator is recommended to store the remote control carefully in order to initialize it if the password is lost.







SNR-73207W

SNC-79447BW

18.2 m (60 ft) Power Extension Cable








Ethernet cable

HDMI Cable

Remote Control / Remote Control Battery (AAA x 2)








Mouse


Screw x 3EA (per Camera) / Anchor x 3EA (per Camera) Power adaptor for NVR / Power adaptor for 4 Cameras




Quick Guide



1. Connect the mouse to the USB Port on the front or back panel of the NVR.




2. Depending on the monitor port, connect the HDMI or VGA cable from your monitor to the HDMI or VGA Port on the rear panel.




NVR Setup


3. Connect one end of the Ethernet cable into your router's LAN port, and the other end of the cable to the WAN port on the rear panel.



4. Install the cameras on the walls and connect the power adapters to each camera.




5. Connect the power adapter for NVR to the DC 12V port on the rear panel and the power plug into a wall outlet. The NVR will display live video feeds from your cameras and then start recording. You will briefly see a live video on display before you start the Startup Wizard. If the camera video is not displayed on the screen, manually pair the camera with the NVR again using the Pair button on the camera. To see how to pair them, see page 11.



Startup Wizard Guide

Change your password on a regular basis.



- ✓ Please create a user name and password for your device. Password MUST be 8~13 characters long. When password is 8~9 characters long, it should be with at least a combination of letters, digits and special symbols. If it is 10~13 characters long, it should be with at least a combination of two types of characters. 4 or more contiguous or repeated characters or key arrangement are prohibited, for example 1111, 1234, abcd, qwerty.
 - 1. After NVR startup is completed, the startup wizard will be displayed. Click "Start Wizard".




Startup Wizard Guide

2. Network


In DHCP mode the router will automatically assign an IP address to NVR.

If the NVR fails to obtain an IP address, refer to the NVR Router Guide. If the problem still cannot be resolved, contact technical support.




3. Date/Time

Set the date, time, NTP, DST.




4. Disk

New hard drive(s) connected must be formatted before use. Upon connection, it will indicate to format new hard drive. Click on "Select" to select the unformatted hard drive. Click on "Format HDD" to pop up the user login window and enter the password to log in. A notice window will indicate "Entire Data Will Be Erased. do You Want To Continue?". Click "OK" to format the disk. When the progress bar is complete, the formatting process is completed.



5. Resolution

Select the resolution for the VGA output or HDMI output of your monitor.



Startup Wizard Guide


6. Mobile

If you scan a QR code using WisenetLife App, the device ID displayed in the NVR will be automatically reflected in the Mobile Viewer ID, and you can use the Mobile Viewer immediately by entering the password of the NVR.



7. Summary

Shows system and network status of NVR.




- **8.** Click on "Finish" to finish setting of startup wizard.
 - ✓ You can click on "Don't show this window next time" if you do not wish to have the wizard setting to appear next time.

Main Interface

In real-time preview mode: right click on any area to access the desired menu. Right click on it to open a context menu. Menu items may vary depending on the condition, such as sign-in, sign-out, split screen mode and various operation conditions.

Left click on any channel to access shortcut menu. Image capture, recording and image zoom-in are in this section.



The video recording marks are shown below

- •: means common Recording.
- ★: means Motion detection recording.
- **PIR**: means PIR detection.

1	Channel Name	Display channel name
2	Date & Time	Display current date and time
3	The WiFi signal icon	The level of the signal, strong or weak.

Main Interface

4	Video Loss	Camera is off-line
5	Manual Recording	Enable or disable manual recording
6	Manual Capture	Make a snapshot of current video
7	Instant Playback	Playback of the last five minutes of the video
8	Zoom	Hold and drag mouse cursor to select a frame of current video to zoom in
9	Color Setting	Set hue, brightness, contrast and saturation of current channel
10	Stream Switch	Mainstream or Substream optional.
•	Pair	Do the pairing of camera and NVR. If you click the icon of each channel and press the Pair button on the camera within 30 seconds, the camera and NVR are manually paired.
P	Main Menu	Access the main menu
B	4-Channel Layout	Display 4 channels of video
14	Auto SEQ	Press this button to switch the screen mode in sequence
B	Play	Replay video recorded
16	Stream Switch	HD or SD optional.
1	Connection state	Display the network connection status
		connect fail: Not connected WAN.
		not connect : Not connected physically.
		connect success : connected WAN.
18	Manual mode	Set manual recording mode
19	System	System Information


Remote Viewing & Cloud Service

Once you've set up your system, you can access to your cameras from anywhere, anytime using Wisenet Life Cloud service.

✓ The appearance of the viewer may differ from the image shown.

[With your PC]

- 1. OS and browser environment
 - OS requirements:
 - Windows 7 or higher
 - Mac OS 10.12 or higher
 - Browser requirements
 - Please use the latest version of the Chrome (Windows OS), or Safari (Mac OS) browsers.
- 2. Start Wisenet Life monitoring & Cloud Service
 - 1) Open your web browser and go to wisenetlife.com
 - 2) Click the "Web Viewer Sign In" button to proceed with signing up. You will need to verify your registered e-mail account to complete the signup. If you already have a Wisenet Life account, log in and register your product.
 - 3) After logging in, proceed with device registration.
 - 4) Enter the serial number on the bottom of the device's QR code as the QR code ID.
 - 5) Enter your Device Password of your NVR.
 - You can only log in with an admin account.
 - 6) Create a name for your NVR and complete the registration.



Remote Viewing & Cloud Service

[With Mobile Devices]

- 1. Recommended Mobile OS version
 - Android: v6.0 or higher
 - iOS: v10.0 or higher
- X Some functions may not work properly depending on the manufacturer of the mobile device
- 2. Start Wisenet Life monitoring & Cloud Service
 - 1) Open Google Play or the App Store and download the free Wisenet Life app.
 - 2) Once installed, open the Wisenet Life app.
 - 3) Click the "Sign Up" button to proceed with signing up.
 You will need to verify your registered e-mail account to complete the signup.
 If you already have a Wisenet Life account, log in and register your product.
 - 4) After logging in, tap or click [+] to add a new device.
 - 5) Scan QR code
 - 6) Enter your Device Password of your NVR.
 - You can only log in with an admin account.
 - 7) Create a name for your NVR and complete the registration.









[Works with the Google Assistant]

Wisenet video security system is compatible with Google assistant and chromecast. For more details, please visit www.wisenetlife.com

User Interface





Main Menu

Find the Information about your plan and notice and turn on/off your alert from the app




Device name

You can check the live and event images of the device.

 The split screen configuration differs depending on the OS type.

Remote Viewing & Cloud Service



3 **Device Setup**You can change the settings of the device.



5 View mode View mode can be changed.




4 List Editor You can change the display position of the device.



6 Add Device
New devices can be added.

App Interface

Live & Playback



App Interface

- Cloud: Motion

- Device: All Events/Motion

Go into single view mode
2 or 4 Channel Split-Screen view
Multi channel image capture
Ul guide
Change to full screen mode
Manual record and save
Image capture
Go into Event list page
Go back to live page
Select storage location
Refresh the event list
Event type

Camera Installation Template

To make camera installation easier, you can tear off this page and adhere it to the place you would like to install your cameras.

TEMPLATE

This template is used to install the camera on the wall

